

RAKL INSTALLATION PROCEDURE FOR THE MONOTOR

1. Remove the front panel socket head 4-40 screws with a 3/32" Allen key.
2. Remove the push-fitted level knob and the big switch knob, the shaft of the switch is slightly below spec, so there is a tape shim on the shaft so the knob won't be loose; this is normal.
3. Remove the nuts and washers on the phone jack(s) with a 1/2" nut driver.
5. Remove the front panel.
7. Remove the plastic frame and save for if you want to return the unit to standalone later.
8. The rack kit RAKL extrusion replaces the plastic frame piece. So bring the front panel to the front of the rack kit RAKL extrusion.
10. With just the RAKL in place and the front panel on, put the nuts and washers back on the jacks but leave them loose. Be careful with the LEDs! This will make it slightly easier to perform the next step.
11. Carefully line up and screw the 4-40 Allan heads back in through the front panel, the RAKL, and into the chassis extrusion. Preferably use the longer socket heads 4-40 that came with the rack kit, but they are not essential.
12. Push the knobs on. You're done!

The little square pieces of metal included (pic below) are for the edges of your rack, so the rack screws sit flush with the RAKL.
Blank panels (not included) are available as part # BLP.

