

RAKL INSTALLATION PROCEDURE FOR REDEYE 3D

1. Remove the front panel socket head 4-40 screws with a 3/32" Allen key.
2. Remove the push-fitted level knob.
3. Remove the front decorative panel.
5. Remove the nuts on the phone jack with a 1/2" nut driver.
6. Remove the sub-panel.
7. Remove the plastic frame and save for if you want the unit standalone at a later date.
8. The rack kit RAKL extrusion replaces the plastic frame piece. So bring both the decorative and bare aluminum sub panel to the front of the rack kit RAKL extrusion. Be careful not to lose (on the inside) the fiber washers on the jacks (they are necessary spacers).
9. Line the holes up where the socket head 4-40 screws go, and with just the utility panel installed on the front of the rack, temporarily screw them in. This is optional but makes it easier to install nuts on jack and potentiometers and keep everything lined up.
10. Put the nuts back on the jacks with just the utility panel on.
11. With the rack on and the Redeye 3D placed so it won't get budged, carefully remove the socket head 4-40 screws and then put the decorative panel on and screw the socket heads 4-40 back in. Preferably use the longer socket heads 4-40 that came with the rack kit, but they are not essential.
12. Push the knob on. You're done!

The little square pieces of metal included (pic below) are for the edges of your rack, so the rack screws sit flush with the RAKL.
Blank panels (not included) are available as part # BLP.

